



ADVANCED SUSPENSION TECHNOLOGY

## Mounting instructions for MN 992



The std nut on top A-arm needs to be replaced with with the new nut provided in the kit.

Apply green Loctite 2700 on threads and tighten nut to specification. Cut off the redundant threds flush to the nut to make sure there is clearece for the bigger diameter spring on the Öhlins shock.



Top bolt on upper shock bracket that is bolted to the frame needs to be replaced with new allen bolt and nut provided in kit to make room for the new Öhlins shock.

**Warning platic bushings needs to be changed every 5000 kilometers / 3100 miles.**